



CUT LIST for HOW TO BUILD MEDICINE CABINET

We built a medicine cabinet with a frame 20 inches wide, 5 3/4 inches deep, and 30 3/4 inches tall. (Note: Counting the crown molding, the finished cabinet measures 25 1/2 inches wide, 8 1/2 inches deep, and 32 3/4 inches tall.)

Frame

1x6 clear pine top and bottom pieces: two @ 18 1/2 inches, ripped to 5 inches wide

1/2-inch pine plywood back panel: one @ 18 1/2 inches by 28 1/2 inches

1x6 clear pine side pieces: two @ 30 inches, ripped to 5 inches wide

1x8 clear pine base board: one @ 21 1/2 inches, ripped to 5 3/4 inches wide

3/8-inch pine cove molding for shelf supports: four @ 4 1/4 inches long

1x6 clear pine shelves: two @ 18 3/8 inches, ripped to 4 1/4 inches wide

1x2 clear pine crosspiece: one @ 20 inches

2 3/4-inch solid poplar crown molding Cut to fit.

Door

1x4 clear pine rails: two @ 15 inches

1x3 clear pine stiles: two @ 28 3/8 inches

3/8-inch pine cove molding to trim mirror Cut to fit.

1/4-inch high-density fiberboard (HDF) mirror backing: one @ 18 1/2 inches by 26 7/8 inches

Mirror: one @ 21 1/8 inches by 14 3/4 inches by 1/8 inch thick

